



**Marantz CD 84 / CD 74** Decoder P500 shown from the component side

**Installation metronom base**

- Desolder TDA1540 or existing sockets
- soldering in metronome modules
- Remove capacitors at Pin8 and 9
- Insert TDA1540 into the modules

**Installation OP amp**

- 604-825 or 604-4031 channel right Q523
- 825-604 or 4031-604 channel left Q525
- different wiring, do not interchange
- solder in firmly, socket not recommended

**Installation attenuated NOS bridge**

- desolder Digitalfilter SAA7030
- solder in attenuated nos bridge
- isolate SAA7000 pin16 with two cuts from traces
- connect pin16 with 1kOhm resistor to pin18 (undersite)
- connect pin17 with 1kOhm resistor to ground (undersite)
- cut the wire bridge
- wire connection from NOS bridge pin7 to cutted wire bridge